

H78/UM Switch Chart							
Switch Bank Zero	First Upper Playfield	Wire Color	Switch Bank One	Second Upper Playfield	Wire Color		
0	None	N/A	8	None	N/A		
1	None	N/A	9	None	N/A		
Key	Key	Key	10	None	N/A		
2	None	N/A	Key	Key	Key		
3	None	N/A	11	None	N/A		
4	Upper Left EOS	Blue	12	Left Spinner	Blue		
5	Middle Left	Green	13	Right Spinner	Green		
6	Upper Scoop	Yellow	14	Upper Entry	Yellow		
7	Middle Right	Orange	15	Upper Right EOS	Orange		
Ground		Black	Ground		Black		
Switch Bank Two		Wire Color	Switch Bank Three		Wire Color	GI Bank 0	Wire Color
16	Trough 5	Purple	24	None	N/A	Key	Key
17	None	N/A	25	None	N/A	0	None
18	Trough 7	White	26	Second Upper Drop Target	Gray	1	Topper
19	Trough 6	Red	27	Three Drop 2	Red	2	Backboard 4
Key	Key	Key	28	Three Drop 3	Purple	3	None
20	Trough 4	Blue	Key	Key	Key	4	None
21	Trough 3	Green	29	Three Drop 1	Green	5	Backboard 3
22	Trough 2	Yellow	30	Middle Drop Target	Yellow	6	Backboard 2
23	Shooter Lane	Orange	31	Extra Ball	Orange	7	Backboard 1
Ground		Black	Ground		Black	Power	Pink
Switch Bank Four		Wire Color	Switch Bank Five		Wire Color	GI Bank 1	Wire Color
32	Extra Ball	Green	40	None	N/A	8	None
33	Right Outlane	Gray	41	Left Ramp Exit	Gray	Key	Key
34	None	N/A	42	None	N/A	9	None
35	Right Orbit	Red	43	None	N/A	10	Ramps
36	Right Flipper EOS	Purple	44	None	N/A	11	Right Inlane
37	Right Sling	Blue	45	None	N/A	12	Right Outlane
Key	Key	Key	46	None	N/A	13	Right Scoop
38	Standup Target 6	Yellow	Key	Key	Key	14	Left Outlane
39	Standup Target 5	Orange	47	None	N/A	15	Left Inlane
Ground		Black	Ground		Black	Power	Pink
Switch Bank Six		Wire Color	Switch Bank Seven		Wire Color	Optos	
48	Left Orbit	Orange	56	Coin Left	Gray	0	Jam
49	Left Flipper EOS	Gray	57	None	N/A	1	Trough 1
50	Left Outlane	White	58	None	N/A	2	Left Subway 1
51	Left Sling	Red	59	Coin Right	Purple	3	Magna Drop
52	Target 1	Purple	60	Menu	Blue	4	Mid Ramp Make
53	Target 2	Blue	61	Volume Up	Gray	5	Playfield Drop Scoop
54	Target 3	Green	62	Volume Down	Yellow	6	Right Lift
55	Target 4	Yellow	63	Back Button	Orange	7	Front Right Scoop
Key	Key	Key	Ground		Black	8	Extra Ball Target
Ground		Black	Key	Key	Key	9	Left Subway 2
						10	Left Subway 4
						11	Mid Ramp
						12	Left Bot Scoop
						13	Left Top Scoop
Cabinet 0		Wire Color	Cabinet 1		Wire Color	14	Left Subway 3
80	Right Flipper	Gray	88	None	N/A	15	Left Mid Scoop
81	None	N/A	89	None	N/A		
82	Left Flipper	Yellow	90	Start Light Ground	Brown		
83	Right Upper Flipper	Red	91	Start Light Power	Yellow		
84	Left Upper Flipper	Purple	92	None	N/A		
85	None	N/A	93	None	N/A		
86	Tilt	Green	94	None	N/A		
Key	Key	Key	Key	Key	Key		
87	Start	Orange	95	None	N/A		
Ground		Black					